Datasheet AntSyn for Antenna Synthesis


Overview

The growing demand for wireless connectivity and remote sensing requires antenna solutions customized for optimal system performance, cost, and size. Satisfying multiple performance metrics such as impedance matching, gain, radiation efficiency, and operating bandwidth is a time-consuming process involving numerous iterations and a significant amount of design knowledge. With the expected demand for design experience greatly exceeding the current supply of antenna engineers, an alternative approach such as AntSyn[™] is warranted.

AntSyn is a cloud-based Software as a Service (SaaS,) automated antenna design, synthesis, and optimization tool that takes antenna engineering requirements as input and produces antenna designs as outputs. AntSyn was designed to be used by all levels of experience, from experts to those who are relatively new to antenna design.

Features at a Glance

- The self-guiding templates are intuitive and easy to use, supporting dozens of antenna types ranging from spirals to patch antennas to Yagi and Vivaldi styles, including many types that are only available using computer-based optimization
- Browser-based interface
- Cloud-based execution for faster and more efficient design space exploration
- Proprietary evolutionary algorithm for:
 - Improved antenna performance via smart optimization
 - Exploring novel design options
- Diverse range of antenna types
 - High-efficiency
 - Handset
 - Loaded
 - Electrically small
 - Phased-array
 - Multiband
 - And more
- Data export to:
 - AWR Design Environment[™] (Microwave Office and Analyst[™])
 - ANSYS and CST
 - STEP, DXF, SolidWorks and FreeCAD
 - Excel for performance parameters



cādence°

How it Works


Step 1. The antenna design process in AntSyn is intended to be relatively simple. The first of four steps is to create a project and spec sheet.

Project 'New Project'			
Create SpecSheet			
Project Information			
Date Created: 03/16/2016			
 Project Name New Project			
Notes:			
SpecSheets			
SpecSheet Name	Date Created		Notes
		Status	

Step 2. Input antenna specifications such as frequency band, target impedance match (return loss), gain pattern, and more into the spec sheet and run.

Input VSWR 2 1 Input Impedance 50 Ohms Gain Pattern Optimized Cut # Elevasion Azimuth Symmetry Rotational Othogonal Cut Azimuth BlantStop deg * Gain vs Angle Othogonal Cut Azimuth BlantStop deg * Gain vs Angle * Gain vs Angle	Input VSWR 2 USWR 2 Imput VSWR 2 USWR 2 Imput VSWR Imput Optimized Cut Imput	Imput YSWR 2 1 input impedance 50 Otms. Gain Pattern Optimized Cut III Elivation © Azimuth Imput impedance 50 Otms. Optimized Cut IIII Elivation © Azimuth Imput impedance 50 Otms. Otmogonal Cut Azimuth StartStop deg IIII Can va Angle Imput impedance 50 Otms. IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIII Can va Angle Imput impedance 50 Imput impedance 50 IIIII Can va Angle Imput impedance 50 Imput impedance 50 IIIII Can va Angle Imput impedance 50 Imput impedance 50 IIIII Can va Angle I		Band Start 1 Stop 1.02 GHz * Custom * Num Freqs Auto Auto
Yow 2 1 Input Impedance 50 Ohms Calin Pattern Dpmixed Cut # Elevation @ Azimuth Imput Impedance 50 Ohms Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Ohms Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Ohms Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Imput Impedance 50 Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Imput Impedance 50 Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Imput Impedance 50 Orthogonal Cut # Elevation @ Azimuth Imput Impedance 50 Imput Impedance 50 Imput Impedance Calin vs Angle Imput Impedance 50 Imput Impedance 50 Imput Impedance Calin vs Angle Imput Impedance 50 Imput Impedance 50 Imput Impedance Calin vs Angle Imput Impedance 50 Imput Impedance 50 Imput Impedance Imput Impedance 50 Imput Impedance 50 Imput Impedance 50 Imput Impedance Imput Impedance 50 Imput Impedance 50 Imput Impedance 50 Imput Impedance Imput Impedance 50 Imput Impedance 50 Imput Impedance 50 Imput Impedance I	VSVR 2 1 input impedance 50 Ohme Gain Pattern Optimized Cut # Elevation = Azimuth Impedance 50 Ohme Orthogonal Cut Azimuth StartStop deg Impedance 50 Ohme Impedance for the Elevation = Azimuth Impedance 50 Ohme Impedance 50 Ohme Orthogonal Cut Azimuth StartStop deg Impedance 50 Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth StartStop deg Impedance 50 Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth StartStop deg Impedance 50 Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth StartStop deg Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth StartStop deg Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth Impedance 50 Impedance 50 Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth Impedance 50 Impedance 50 Impedance 50 Impedance 50 Impedance for the Elevation = Azimuth Impedance 50 Impedance 50 Impedance 50	YSWR 2 1 Input Impedance 50 Otms Gain Pattern Optimized Cut & Elevation © Azimuth Symmetry Rotational Impedance Impedance Orthogonal Cut Azimuth StatiStop deg Impedance Impedance Impedance Impedance S0 Otms Otms Impedance Impedance Impedance Impedance Impedance S0 Otms Otms Impedance Impedance <td< th=""><th></th><th></th></td<>		
Cain Pattern Cymiaed Cut & Elevation & Asimuth Symmetry Rotational Orthogonal Cut Azimuth BlantStop dep * Cain vs Angle Con and Beamatch At this angle: 0 50 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Gain Patern Optimized Cut & Elevation & Azimuth Symmetry Instantial Orthogonal Cut Azimuth BtartSlop deg Choogonal Cut Azimuth BtartSlop deg Choogonal Cut Azimuth BtartSlop deg Con and Beamwith At this apple Can shart Slop deg Con and Beamwith At this apple Can shart Slop deg Con and Beamwith At this apple Can shart Slop deg Con a distribute be: deg Con a			Input
Cpenzed Cut # Elevation @ Azimuth Bymmetry Rotational Orthogonal Cut Azimuth BlantStop deg @ Can and Beamsth At this and Beamsth At this and Beamsth This is a constrained beamsth and a constrained beamst	Cypriciad Cut & Elevation & Admuth Symmetry Rotational Orthogonal Cut Admuth BaierStop Beg Can via Angle Can via Angle Can via Baamith Af this angle: Sign Should be: Sign Should be: Should b	Cprinzed Cut & Elevation & Adimunt Symmetry Rotational Orthogonal Cut Adimuth StartStop deg Can vis Anglé Gan vis Anglé G		VSWR VSWR
Symmetry Rotational Criticiponal Cut Azimuth StartStop deg Can via Angle Can via Angle Can via Angle Can and Beamwidth At this angle: Gam should be: Geg Start Can	Symmetry Rotational Orthogonal Cut Azimuth Bart/Stop dep Cain vs Angle Cain vs Ang	Symmetry Rotational Symmetry Rotational Chrisgonal Cut Admuth BartStop deg Chrisgonal Cut Admuth BartStop	_	
Ochogonal Cut Admuth StartStop deg	Crhogonal Cut Azimuth BuritStop Beg	Orthogonal Cut Admuth StartStop deg		Optimized Cut [®] Elevation [©] Azimuth Z ^{0=0*} Z ¹ _{Elev}
** Cain vs Angle Gon and Beamsoth Attin served Gon and Beamsoth Attin served Gon and Beamsoth 100 100 101 100 100 <td>Cain vs Angle Gan and Beamwith Mits angle Gan angle Gan</td> <td>Cain vs Angle Goan and Beamsth Attis Attis Attis Goan and Beamsth Attis Att</td> <td></td> <td>Symmetry Rotational</td>	Cain vs Angle Gan and Beamwith Mits angle Gan	Cain vs Angle Goan and Beamsth Attis Attis Attis Goan and Beamsth Attis Att		Symmetry Rotational
* Cain vs Angle • Cain vs Angle • Cain van decamvoth • O <t< td=""><td>Can vis Angle Gan vis Angle Gan and Beamwoth At this angle Soft should be: Go S</td><td>Cain vs Angle Gan and Beamwith At mis angle S</td><td></td><td>Crithogonal Cut Azimuth Start/Stop deg</td></t<>	Can vis Angle Gan vis Angle Gan and Beamwoth At this angle Soft should be: Go S	Cain vs Angle Gan and Beamwith At mis angle S		Crithogonal Cut Azimuth Start/Stop deg
A This and Becamenth A This and Becamenth A Bia and Becamenth G G G G G G G G G G G G G G G G G G G	Can and Beamwith Athis angle: Cash should be: deg	Can and Beamwith Athis and: Can and Beamwith Can and		ê=90*
At the add Beamworth At the add Beamworth At the add Beamworth Ad	Gon and Beamwith At the angle:: Geg and the semiclater results Run Duality: Low Medium High	Gom and Beamwidth At this angle: Gom and Beamwidth At this angle: Gom bound be: Gom	1	
At the add Beamworth At the add Beamworth At the add Beamworth Ad	Con and Beamston Af the sender: degrader:	Gan and Beamwith At this single: Gain should be: Gain	a line	
A this angle: Qain strud by deg 2 c def 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	At the angle: Gan should be: deg at a difference of the second s	At this angle: deg :: c dB of 5 : 0 : 3 : 0 of 5 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 : 0 : 0 : 0 of 5 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0 : 0 :	101	
deg x = x dBl 0 0 0 0 0 15 0 0 0 0 135 0 0 0 0 135 0 0 0 0 130 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	deg a s cBi 0 a a a a 0 a a a a 0 a a a a 0 a a a a 0 a a a a 0 a a a a 0 a a a a 0 a a a a a a a a a a a a a a a a a a a b a a a a a a a a a a a a a a a a a a a b a a a a b a a a a <tr< td=""><td>deg a s s dB o 5 0 0 3 00 0 5 0 0 0 0 0 15 0 0 0 0 0 15 0 0 0 0 0 10 0 0 0 0 0 10 0</td><td>1</td><td>-15</td></tr<>	deg a s s dB o 5 0 0 3 00 0 5 0 0 0 0 0 15 0 0 0 0 0 15 0 0 0 0 0 10 0 0 0 0 0 10 0	1	-15
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0	0 0 5 mo 0 0 5 mo 0 0 0 0 100 0 0 0 0		At this angle. Gain should be:
0 45 0	45 0 3 00 90 0 0 0 115 0 10 00 115 0 10 00 115 0 10 00 115 0 10 00 115 0 10 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00 00 0 0 00	45 0 3 we 0		
0 90 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		Or O		
	ISS I			
180 10				S
Conception of the second secon				
Contraction of the second seco	Concerning	Concervity Concervity Concer		. 180
C Directivity 1557 to	C Directivity C Dir	C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C Directivity C		0 000 00
C Directivity 100 ⁻¹ K	Directivity	Correctivity Tage Tage Tage		
U Directivity 100° 14	Correctivity Torrectivity T	Construity Construits Const		
The manufacture of the second s	Run Cuality: Low Medium High	Run Cuality: Low Medium High	/	E Sunda
	Send Email when complete Show intermediate results Low Medium High	Run Quality:)	Unrecovity 100
Presequences assume Transition Straphile Transitional Transition Straphile Transitional Transition Straphile Drame	Send Email when complete Show intermediate results Run Quality:	Gend Email when complete Show intermediate results Low Medium High		
	Send Email when complete Show intermediate results Run Quality: Low Medium High	Send Email when complete Show intermediate results Run Quality:		• Prevente and in the last of a product of the second o
	Send Email when complete Show intermediate results Low Medium High	Send Email when complete Show intermediate results Run Oually: Low Medium High		Dun
	Run Guality: Low Medium High	Run Guality: Low Medium High		Cond Email when complete C their intermediate results
Cand Email when complete C Show intermediate results	Run Quality:	Run Dually:		ini gene cinari anen complete ini groar merinebiate regolta
Send Email when complete Show intermediate results				Run Quality Low Medium High
Low Modium Minh	Save Save and Run Cancel Run	Save Save and Run Cancel Run		
Low Modium Minh	save save and rain Cancel Rain			Save Save and Rus Concel Dun
Run Quality:				

Step 3. AntSyn returns one or more optimized antenna designs. The results such as voltage standing wave ratio (VSWR), return loss (dB), complex impedance (Z), max gain vs. frequency, and more are then viewable in a customizable dashboard for rapid evaluation. Additionally, multiple design results can be added to a Compare page where graphs are overlaid for more detailed analysis.



Step 4. Finalize design selection and export to realize endsystem design within AWR Design Environment or your preferred EM simulator.

